

LAMP  
LED

**Kartell**



Taj Mini  
Ferruccio Laviani

## INFORMATIONS PROVIDED BY THE PRODUCER FOR THE PURCHASER

Material: transparent or batch-coloured PMMA, led 2,8W 24v === 50/60Hz

Note: this technical specifications form of the product is in accordance with the Law n. 126 of the 10th April 1991 "Norms regarding consumer information" and with the decree n. 101 of the 8th February 1997 "Implementation regulation". Maintenance instructions: disconnect the lamp from the power supply and clean the product with a damp cloth and soap or neutral liquid detergents diluted with water. **Do not use ethyl alcohol or detergents that contain even small amounts of acetone, trichloroethylene or ammonia (or solvents in general).**

### WARNING

Carefully read instructions for product use, equipment safety is only guaranteed when observed. Therefore they must be kept.

Do not shield the product with objects or clothing that jeopardize operations. Disconnect the power supply upon installation and whenever touching the light bulb. If the equipment power cord is damaged it must only be replaced by qualified personnel using an identical spare part.

Kartell will accept no liability for any damages caused to property or persons subsequent to incorrect handling of the product. If the assistance of the manufacturer is required to rectify faults arising from incorrect installation or use, this assistance is not covered by the guarantee.

### OBJECT IS PROTECTED BY COMMUNITY DESIGN REGISTRATION

#### 制造商致购买者声明

材料：透明或彩色PMMA材质，Led灯,2,8W 24v === 50/60Hz

说明 此产品保修卡遵守1991年4月10日第126号“消费者信息法”和1997年2月8日第101号“贯彻条例”。

维护说明 拔开电灯的电源，用浸透皂液或中性清洗剂 稀释 的湿布清洁本产品

**避免使用乙醇或含有小剂量丙酮，三氯乙烯和氨（溶解）的清洗剂。**

#### 注意

请仔细阅读产品使用说明，产品安全仅在遵照使用说明下才获得保障，因此请务必小心保管

请勿以其它物品或布料盖住本产品，

请在组装产品和触摸灯泡时拔开电源 请使用所指示的灯泡类型，并且不可超过设定的最大功率若电源线损坏，必须让专门人员使用原始备件来替换

企业联合拒绝对于使用不当而造成的所有损失负任何责任。

本保证不包含某些类型的辅助设备或由于对产品使用不当而造成的损坏的修理和赔偿。

本对象受到共同体设计注册的保护

## FUNCTION

Select the correct plug for your country. Insert the plug into the transformer housing until you hear a click (figure 1).

Insert the connector into the housing on the power supply and rotate it 90 ° (figure 2).

## SWITCHING ON AND OFF

To switch on the light, touch near the protruding start of the plastic LED cover with your fingers. To switch off the light, repeat this process. The product is ON/OFF.

## 功能

选择在本品使用所在国家/地区使用的插头。将插头插入变压器的底座，直至听到“咔嗒”声（图1）。将连接器插入电源器上预设的插座并将其旋转90°（图2）。


## 开灯和熄灯

要打开灯体，请用手指触摸小镜片上的凸出部位附近。



要熄灭灯体，请重复之前所做的相同操作。

本产品是开/关型。

1



2





### **USER INFORMATION ON RECYCLING**

If this symbol is found on a Kartell product, it must be disposed of separately from domestic waste. Product recycling: Do not dispose of lighting equipment of electrical components with domestic waste. In fact, in some countries or regions, electric and electronic material is collected separately for recycling. For further information, contact you local authorities, if recycling systems are not available, return lighting material or components to the store where they were purchased.

### **关于再回收的用户须知**

如果 **Kartell** 的产品上带有此标志，意味着该产品应与家庭垃圾分开处理。

产品的再回收：勿将灯体或电气部件与家用垃圾一起处理，在某些国家或地区会设有专门的分类收集系统，用以处理电气或电子类的垃圾。

欲了解详情，请联系当地政府；如果不具备分类收集系统，请将灯体或其元部件返还给您购买本品时的商店。



**Kartell**

Via delle Industrie, 1 • 20082 Noviglio MI • t. +39 02 90012 1 • f. +39 02 9009 1212 • [kartell@kartell.it](mailto:kartell@kartell.it)  
[kartell.com](http://kartell.com)